CABINET PARTS

For Models: GB2SHKXKQ00, GB2SHKXKT00, GB2SHKXKB00
(White) (Biscuit) (Black)

REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GB2SHKXKQ00, GB2SHKXKT00, GB2SHKXKB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT8170713	Tech Sheet
	LIT8170460	Use & Care Guide
	LIT8170707	Energy Guide
3		Plug, Button (3)
	4344209	White
	8170487	Biscuit
	4344208	Black
5	8170506	Roller, Front Assy.
6	4344155	Clip, Grille
7	4344177	Pin, Center Hinge
8		Shim
	4344188	Black
	4344187	White
10		Hinge Cover, Bottom
	4344204	White
	8170490	Biscuit
	4344202	Black
11	4344186	Screw
13	8170540	Shim, Hinge Top
14	4344198	Screw
15	4344431	Hinge, Center
16		Shim, Center Hinge
	4344427	Grey
	8170714	Black
17		Shim
	4344200	White
	4344201	Black
19		Hinge Bottom
	8170636	White
	8170635	Black
20	8170455	Screw
21	4344178	Pin, Bottom Hinge
22		Grille
	4344154	White
	4344572	Biscuit
	4344152	Black
23	4344267	Screw
24	4344264	Plug, I/M
25	4343759	Screw
26	4344257	Wire Cover
27	8170375	Back Cover
28	8170728	Harness, Control
29	4344266	Plate, Water Valve
30	8170377	Cover, Unit
32	4344263	Power Cord
33	4344259	Grommet
34	4344260	PLug
39	4344265	Clip
40		Shim, Hinge
	8170662	White
	8170663	Black
41	8170659	Hinge Top
42		Hinge Cover
	8170379	White
	8170488	Biscuit
	4344195	Black
44	8170380	Screw
45	4344293	Screw
46	4344298	Foot Break
47		Cabinet (Not A Serviceable Part)

FREEZER LINER PARTS

For Models: GB2SHKXKQ00, GB2SHKXKT00, GB2SHKXKB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: GB2SHKXKQ00, GB2SHKXKT00, GB2SHKXKB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
2	4343675	Screw
4	4344205	Light Lens
5	4344206	Screw
6	8170384	Light Socket
7	4343682	Clip−Ground
8	4344396	Screw
9	8170385	Light Bulb
10	8170381	Housing, Frz. Light
11	4344387	Cover, Evaporator
12	4344167	Screw
13	4344211	Washer (2)
14	8170341	Cover, Switch
16	4344571	Switch, Light
17	4344166	Cover, Plug
18	8170456	Screw
19	4344228	Plug, Button
20	4344216	Gasket, Bottom
21	4343886	Gasket, Top (2)
22	4344388	Cover, Fan Shroud
23	4344587	Gasket
25	8170715	Evap, Fan Shroud
27	8170544	Fan, Evaporator
29	8170388	Grommet
30	8170525	Motor, Evaporator
31	8170390	Spacer
32	8170391	Screw (2)
33	4344227	Plug, Button
34	4344222	Duct, Return Air
36	4343860	Screw
37	4344214	Knob, Control
38	4344224	Screw
39	8170392	Cover, Frz. Control
40	4343861	Screw
41	4344225	Thermostat
43	4344578	Bracket, Control
44	4344316	Plug, Button
45	4344321	Grommet
47	4344385	Funnel−Drain (Includes 48 & 49, seal & gasket)
48	8170729	Seal
49	4344310	Gasket

FREEZER DOOR PARTS

For Models: GB2SHKXKQ00, GB2SHKXKT00, GB2SHKXKB00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1		Freezer Door Panel (Includes Insulation)
	8170459	White
	8170496	Biscuit
	8170457	Black
2		Handle
	4344162	White
	8170485	Biscuit
	4344160	Black
3		Plug, Button
	4344159	White
	8170484	Biscuit
	4344157	Black
4	8170396	Screw
5	4344355	Interior Panel
6	4344582	Trim, Shelf
7	4344352	End Cap
8		Door Gasket, Magnetic
	8170634	White
	8170655	Black
10	4344350	Insulation
12		Door, Stop
	4344463	White
	4344563	Black
	8170494	Biscuit
13	4344333	Screw
14		Plug, Button
	4344535	White
	4344533	Black
	8170495	Biscuit
17		Bushing
	4344362	White
	4344361	Black
18		Plug, Button
	4344227	White
	4344364	Black
19	4343811	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR LINER PARTS

For Models: GB2SHKXKQ00, GB2SHKXKT00, GB2SHKXKB00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	8170381	Housing, Ref. Light
4	4344571	Light Switch
5	4343682	Ground Clip

Illus. No.	Part No.	DESCRIPTION
6	4344167	Screw
11	4344396	Screw (12)
12	8170709	Egg Bin
13	4344321	Grommet
15	8170444	Control, Damper
16	8170727	Insulation, Damper
17	8170383	Shield, Light
18	8170384	Socket, Light

Illus. No.	Part No.	DESCRIPTION
20	8170385	Light Bulb
21	8170386	Light Lens, Top
22	4343675	Screw
23	4343681	Gasket, Damper
25	8170371	Cover, Control
26	4344180	Knob, Control
29	4344241	Plug, Button

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: GB2SHKXKQ00, GB2SHKXKT00, GB2SHKXKB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: GB2SHKXKQ00, GB2SHKXKT00, GB2SHKXKB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door Panel (Includes Insulation)
	8170493	White
	8170492	Biscuit
	8170491	Black
2	4344340	Interior Panel
3		Door, Compartment
	4344335	Left Side
	4344336	Right Side
4	8170393	Trim, Comp. Door
8		Door Gasket, Magnetic
	8170638	White
	8170654	Black
9		Door Handle
	8170477	White
	8170476	Biscuit
	8170475	Black
10	4344342	Hinge Pin
12	4344251	Shelf Bin (4)
13		Trim, Handle
	8170480	White
	8170479	Biscuit
	8170478	Black
14	4344583	Trim, Door Shelf
16	4344346	Plug−Trim
17		Stop, Door
	4344463	White
	8170494	Biscuit
	4344563	Black
18		Plug, Button
	4344535	White
	8170495	Biscuit
	4344533	Black
19	4343811	Screw
21	4344333	Screw
22	8170499	Screw
23		Bushing
	4344362	White
	4344361	Black
24		Plug, Button
	4344227	White
	8170497	Biscuit
	4344364	Black
25		Nameplate
	4344577	White
	8170486	Biscuit
	4344575	Black

UNIT PARTS

For Models: GB2SHKXKQ00, GB2SHKXKT00, GB2SHKXKB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: GB2SHKXKQ00, GB2SHKXKT00, GB2SHKXKB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	4343865	Screw
2	4344271	Fan, Blade
3	8170489	Condenser & Pan Assembly
4	4344599	Screw
5	4343691	Screw
6	4343860	Screw
7	4344217	Heat Shield
8	4344394	Drain Pan
10	4344232	Evaporator Heater
12	8170706	Overload (Includes Relay)
13	4344275	Gasket
14	4344231	Bi−Metal
15	8170724	Strap
16	4344278	Bracket, Timer
17	8170462	Capacitor
19	4343969	Clip, Wire
20	4344389	Drain Pan
22	8170402	Evaporator
24	8170704	Motor, Fan
25	4343918	Clip, Heater
26	8170703	Harness, Unit
27	4344268	Drier
28	8170699	Compressor (Includes Items 11, 12, 15, 17 & 27)
30	4344282	Washer
31	4344554	Shroud
32	4344272	Bracket, Fan Motor
33	4344395	Screw (2)
34	4343763	Clip, Drier
35	8170451	Cover, Timer
36	4344234	Block, Evaporator
37	4343759	Screw
38	8170404	Timer, Defrost
39	4343845	Grommet (4)
40	4344562	Screw
42	4344219	Clip, Evaporator
43	4343772	Screw
44	4343847	Screw
45	4344545	Screw
46	4343661	Clamp
48	4343749	Screw
49	4344297	Cabinet, Brace
50	4344396	Screw
51	4344289	Axle−Roller
52	4344288	Roller−Rear
53	4344292	Screw
54	4344287	Plug, Button
55	4344283	Drain Tube
58	4343777	Clamp, Tube

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

4.5 Ozs.
(R−134A)

SHELF PARTS

For Models: GB2SHKXKQ00, GB2SHKXKT00, GB2SHKXKB00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	4344581	Support, Crisper RS
2	4344580	Support, Crisper LS
3	8170399	Ice Bucket
4	8170400	Shelf, Frz. Wire
5	8170310	Basket, Freezer
6	8170311	Handle, Basket
9	4344236	Meat Pan
10	4344381	Shelf, Meat Pan S/G
11	4344243	Frame Assy, S/O
12	4344380	Shelf, S/G, S/O
13	8170562	Rack, Ice Tray
14	4344171	Tray, Ice Cube
15	4344239	Spacer
16	4344238	Screw
17	4344252	Crisper Pan
18	4344255	Support, Crisper Cvr
19	4344256	Gasket
20	4344254	Cover, Pan
21	4344383	Glass, Crisper Cover
22	8170721	Ladder, Center
23	8170730	Ladder, Side
24	4344396	Screw
25	4344324	Screw
26	2192761	Trim, Meat Pan
27	2179342	Slide, Humidity Control
28	2179343	Body, Humidity Control
29	2192763	Trim, Crisper pan
30	4343675	Screw
31	4344294	Rack, Wine

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LITERATURE AND OPTIONAL PARTS

For Models: GB2SHKXKQ00, GB2SHKXKT00, GB2SHKXKB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

Customer Touch−Up Material

	*350942	Primer, White (13 Oz. Spray Can)
	*350939	Enamel, Black (13 Oz. Spray Can)
	*350930	Enamel, White (13 Oz. Spray Can)
	*350956	Enamel, Almond (13 Oz. Spray Can)
	72017	Brush Touch−Up Kit (White)
	72107	Brush Touch−Up Kit (Almond)
	72032	Brush Touch−up kit (Black)

*__Caution:__ The spray paint is not to be used where the paint may make contact with the door gaskets.

Refinishing Material

	799340	Enamel, Black (1 Qt. Uncut)
	799344	Enamel, White (1 Qt. Uncut)
	978883	Enamel, Almond (1 Qt. Uncut)

Miscellaneous

	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")
	876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")
	978941	Insulation, Fiberglass (63−1/2" x 35−1/2" X 2−5/8)
	876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
	505587	Sealer, Mastic (1 Qt.)
	503695	Cork, Sealer (1/4 Pound)
	511873	Touch−Up, White Porcelain (2 Oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1−1/4 Oz.)
	606755	Bag, Insulation (36−5/8" x 46")
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	833938	Kit, Terminal Connector
	4343700	Ice Container Assembly

TORX SCREW WRENCH

	1117510	Torx Key

ICE MAKER FIELD INSTALLABLE

	4344173	AMKIT97